

# General Rules For All Pullers

*Antique Edition*

- 1. Safety first! Always think safety, always act safely. Drive slowly, look around and think of others.**
2. All contestants enter at their own risk.
3. Order of pull within each class will be determined by lottery drawing at registration. All tractors must post pull number on side of tractor.
- 4. Drivers under age 18 must have written permission form parents or guardians to enter tractor pull and/or present a farm safety course certification.** Drivers must be 16 or over to drive in open or un-paced classes.
5. Driver must remain in seat at all times and operate the tractor in a safe manner at all times on and off the track.
6. Kill switches, wheelie bars and fenders are highly recommended but not mandatory except in un-paced classes. Wheelie bars must be strong enough to hold tractor when tested. If no wheelie bars, the tractor will be flagged to stop when the front wheels exceed knee high above the ground.
7. All tires must be on the tractor, no tracks allowed.
8. All tractors will be weighed and drawbar checked as you line up for your class, any tractor can be re-weighed after pull by promoter's request.
9. The pull will start with a tight hook-up; NO JERKING!
10. If anything falls off the tractor before it is unhooked from the eliminator, the tractor is disqualified.
11. The officials have the right to stop any entry at any time during the pull. Pay attention to the officials, their word is final.
12. Any tractor violating track boundary will be measured from that point if they stop promptly, otherwise, it will be DQ'd.
13. Drawbar height not to exceed 20" for all classes, except stock antique, which will be 18". Drawbar must be at least 18" back of center of rear axle. Drawbar must be rigid in all directions (NO FLOATING DRAWBARS!). Tractors must be equipped with a 2 ½" clevis or pulling eye. Height will be checked on scale.
14. Only one pull per weight class per tractor unless a tie requiring a pull-off or sled reset.

15. No alcohol may be consumed by drivers before or during pulling a tractor.
16. All drivers are to be in line and ready to pull at the start of their weight class.
17. No registrations after the start of each respective class.
18. Official decisions made at drivers meeting take priority over printed rules.
19. Paced classes will be paced with a speedometer on the sled and a horn sounding when speeding, after the 100 foot cone, any horn blowing will result in a DQ.
20. No Massey 44, Oliver 88, M, MU and UB shall enter any class below 4600.
- 21. HAVE FUN: THAT IS WHAT WE ARE ALL HERE FOR!!!!**

## Additional Rules For Antique Stock Classes

1. Tractor must be 1957 or older.
2. HP & RPM: NO more than 10% over on HP or RPM's allowed according to the Nebraska Test. Working PTO, unaltered positive throttle stop and working governor are mandatory. RPM's will be checked if in questions and HP will be checked if dyno is available.
3. Tires: 15.5 up to 5000 lbs, 16.9 in classes over 5000. No cuts of any kind.
4. Tractor must have stock block, carburetor and serial number attached for make and model.
5. Tractor will run on stock fuel only.
6. Speed: low gear only, not to exceed 3 mph.
7. Weights: must be secured safely and securely to tractor. No weights in front of front casting, or beyond rear tires.
8. Drawbar height max will be 18" and no closer than 24" from center of axle.

## Additional Rules For Antique Paced Classes






1. Tractor must be 1957 or older.
2. HP & RPM: Any horsepower is allowed
3. Tires: Maximum rear tire size is 16.9x38 up to 4750 and 18.4x38 above 4750.
4. Weights: weights may not extend more than 24" in front of the tractor casting and rearward no more than the rear edge on the tires. They will be securely fastened.

5. Drawbar height max: 20" in all classes (rigid in all directions).
6. Tractors must have stock block for the make and model. No alcohol fuel, no nitrous gas or ether is allowed. Officials have the right to test and inspect the fuel.
7. Pace: the pace is 4mph, you will have 100 feet to set your speed, after the cone, if horn blows, you will be DQ'd.
8. **2 hooks per tractor during the event!!!**

## Additional Rules for Un-Paced Antique Class

1. Tractor must be 1957 or older.
2. Any HP is allowed, if RPM's exceed twice the factory specs, then safety should be used.
3. Tires: Maximum rear tire size is 16.9x38 up to 4750 and 18.4x38 above 4750.
4. Weights: weights may not extend more than 24" in front of the tractor casting and rearward no more than the rear edge on the tires. They will be securely fastened.
5. Drawbar height max: 20" in all classes (rigid in all directions).
6. Tractors must have stock block for the make and model. No alcohol fuel, no nitrous gas or ether is allowed. Officials have the right to test and inspect the fuel.

## Winnebago County Pull Additional Rules

-  Tractors can pull in only one class
-  NO CARRY INS ALLOWED!
-  Two wristband passes per paid 15\$ tractor entry fee. Wristbands are for grounds admission only, carnival rides are extra.
  
-  Registration begins at 9am on Saturday August 9<sup>th</sup> for the antique classes.
  
-  Antique class pull begins at 11:00am

Questions can be directed to the fair office at 920-231-6002

Classes and schedule are subject to change.

## Antique classes are:

3500 Paced  
3750 No-Pace  
4000 Stock  
4500 Paced  
4750 No-Pace  
5000 Stock  
5500 Paced  
5750 No-Pace  
6000 Stock  
6500 Paced  
6750 No-Pace  
7500 Paced